



# Certificate of Analysis

Sample: TE40131001-002

Harvest/Lot ID: 2400113

Batch#: 2400113

Batch Date: 01/31/24

Sample Size Received: 62.44 gram

Total Amount: 1 units

Retail Product Size: 46.2 gram

Ordered: 01/31/24

Sampled: 01/31/24

Completed: 02/06/24

Feb 06, 2024 | e2e Pharma

3279 E. Harbour Drive  
Phoenix, AZ, 85034, US



**PASSED**

Pages 1 of 6


## PRODUCT IMAGE



## SAFETY RESULTS



Pesticides  
**PASSED**



Heavy Metals  
**PASSED**



Microbials  
**PASSED**



Mycotoxins  
**PASSED**



Residuals Solvents  
**PASSED**



Filtration  
**PASSED**



Water Activity  
**NOT TESTED**



Moisture  
**NOT TESTED**



Terpenes  
**NOT TESTED**

## MISC.



## Cannabinoid

**PASSED**



Total THC

**0.0000%**

Total THC/Container : 0.000 mg



Total CBD

**4.4403%**

Total CBD/Container : 2051.419 mg



Total Cannabinoids

**4.4403%**

Total Cannabinoids/Container : 2051.419 mg

	D9-THC	THCA	CBD	CBDA	CBG	CBGA	CBN	D8-THC	THCV	CBDV	CBC
%	0.0000	ND	4.4403	ND	ND	<0.0050	ND	ND	ND	<0.0070	ND
mg/unit	0.000	ND	2051.419	ND	ND	<2.310	ND	ND	ND	<3.234	ND
LOD	%	%	%	0.0020	0.0020	0.0010	0.0010	0.0020	0.0020	0.0020	0.0010

Analyzed by:  
39, 135, 312, 272, 333

Weight:  
0.7731g

Extraction date:  
02/02/24 13:26:56

Extracted by:  
39

Analysis Method : SOP.T.30.500, SOP.T.30.031, SOP.T.40.031

Analytical Batch : TE003816POT

Instrument Used : TE-005 "Lady Jessica" (Concentrates)

Analyzed Date : 02/02/24 13:30:55

Reviewed On : N/A

Batch Date : 01/31/24 16:37:40

Dilution : 40  
Reagent : N/A  
Consumables : N/A  
Pipette : N/A

Full spectrum cannabinoid analysis utilizing High Performance Liquid Chromatography with Photo Diode Array detector (HPLC-PDA) for analysis. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.031 for sample prep, SOP.T.40.031 for analysis on Shimadzu LC-20X0 series HPLCs). Potency results for cannabis flower products are reported on an "as received" basis, without moisture correction.

This Kaycha Labs Certification shall not be reproduced, unless in its entirety, without written approval from Kaycha Labs. The results relate only to the material or product analyzed. ND=Not Detected, ppm=Parts Per Million, ppb=Parts Per Billion, RSD=Relative Standard Deviation. Limit of Detection (LOD) and Limit Of Quantitation (LOQ) are terms used to describe the smallest concentration that can be detected and reliably measured by an analytical procedure, respectively. Action Levels are State-determined thresholds based on the action limits published in Table 3.1 of 9 A.A.C. 17 and 9 A.A.C. 18. The Measurement of Uncertainty (MU) error is available from the lab upon request. The "Decision Rule" for pass/fail does not include the MU. Any calculated totals may contain rounding errors.

**Ariel Gonzales**

Lab Director

State License #  
00000024LCMD66604568  
ISO 17025 Accreditation # 97164

Signature  
02/06/24



1231 W. Warner Road, Suite 105  
Tempe, AZ, 85284, US  
(480) 220-4470

Kaycha Labs

Social CBD Gel Caps Daily 2000mg 60ct

Matrix : Infused

Type: Capsule



# Certificate of Analysis

PASSED

e2e Pharma

3279 E. Harbour Drive  
Phoenix, AZ, 85034, US  
Telephone: (602) 737-0077  
Email: shannon.bard@e2epharmamfg.com

Sample : TE40131001-002

Harvest/Lot ID: 2400113

Batch# : 2400113

Sampled : 01/31/24

Ordered : 01/31/24


Sample Size Received : 62.44 gram

Total Amount : 1 units

Completed : 02/06/24 Expires: 02/06/25

Sample Method : SOP Client Method

Page 2 of 6

 Pesticides						PASSED					
Pesticide	LOD	Units	Action Level	Pass/Fail	Result	Pesticide	LOD	Units	Action Level	Pass/Fail	Result
AVERMECTINS (ABAMECTIN B1A)	0.0170	ppm	0.5	PASS	ND	TOTAL SPINOSAD	0.0060	ppm	0.2	PASS	ND
ACEPHATE	0.0100	ppm	0.4	PASS	ND	SPIROMESIFEN	0.0080	ppm	0.2	PASS	ND
ACETAMIPRID	0.0050	ppm	0.2	PASS	ND	SPIROTETRAMAT	0.0060	ppm	0.2	PASS	ND
ALDICARB	0.0140	ppm	0.4	PASS	ND	SPIROXAMINE	0.0040	ppm	0.4	PASS	ND
AZOXYSTROBIN	0.0050	ppm	0.2	PASS	ND	TEBUCONAZOLE	0.0040	ppm	0.4	PASS	ND
BIFENAZATE	0.0060	ppm	0.2	PASS	ND	THIACLOPRID	0.0060	ppm	0.2	PASS	ND
BIFENTHRIN	0.0050	ppm	0.2	PASS	ND	THIAMETHOXAM	0.0060	ppm	0.2	PASS	ND
BOSCALID	0.0050	ppm	0.4	PASS	ND	TRIFLOXYSTROBIN	0.0060	ppm	0.2	PASS	ND
CARBARYL	0.0080	ppm	0.2	PASS	ND	CHLORFENAPYR *	0.0270	ppm	1	PASS	ND
CARBOFURAN	0.0050	ppm	0.2	PASS	ND	CYFLUTHRIN *	0.0150	ppm	1	PASS	ND
CHLORANTRANILIPROLE	0.0110	ppm	0.2	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.104.AZ Analytical Batch : TE003858PES Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Pesticide screening is carried out using LC-MS/MS supplemented by GC-MS/MS for volatile pesticides. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.104.AZ for analysis on ThermoScientific Altis TSQ with Vanquish UHPLC).</div>					
CYPERMETHRIN	0.1000	ppm	1	PASS	ND						
DIAZINON	0.0060	ppm	0.2	PASS	ND						
DAMINOZIDE	0.0100	ppm	1	PASS	ND						
DICHLORVOS (DDVP)	0.0010	ppm	0.1	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
DIMETHOATE	0.0060	ppm	0.2	PASS	ND						
ETHOPROPHOS	0.0040	ppm	0.2	PASS	ND						
ETOFENPROX	0.0060	ppm	0.4	PASS	ND						
ETOXAZOLE	0.0040	ppm	0.2	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
FENOXYPYR	0.0050	ppm	0.2	PASS	ND						
FENPYROXIMATE	0.0040	ppm	0.4	PASS	ND						
FIPRONIL	0.0060	ppm	0.4	PASS	ND						
FLONICAMID	0.0090	ppm	1	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
FLUDIOXONIL	0.0060	ppm	0.4	PASS	ND						
HEXYTHIAZOX	0.0050	ppm	1	PASS	ND						
IMAZALIL	0.0110	ppm	0.2	PASS	ND						
IMIDACLOPRID	0.0080	ppm	0.4	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
KRESOXIM-METHYL	0.0070	ppm	0.4	PASS	ND						
MALATHION	0.0070	ppm	0.2	PASS	ND						
METALAXYL	0.0040	ppm	0.2	PASS	ND						
METHIOCARB	0.0040	ppm	0.2	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
METHOMYL	0.0050	ppm	0.4	PASS	ND						
MYCLOBUTANIL	0.0100	ppm	0.2	PASS	ND						
NALED	0.0070	ppm	0.5	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
OXAMYL	0.0080	ppm	1	PASS	ND						
PACLOBUTRAZOL	0.0050	ppm	0.4	PASS	ND						
TOTAL PERMETHRINS	0.0030	ppm	0.2	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
PHOSMET	0.0100	ppm	0.2	PASS	ND						
PIPERONYL BUTOXIDE	0.0050	ppm	2	PASS	ND						
PRALLETHRIN	0.0130	ppm	0.2	PASS	ND						
PROPICONAZOLE	0.0050	ppm	0.4	PASS	ND	<div>Analized by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/06/24 10:10:11 Extracted by: 152 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.154.AZ Analytical Batch : TE003859VOL Instrument Used : TE-118 "MS/MS Pest/Myco 1", TE-261 "UHPLC - Pest/Myco 2" Analyzed Date : N/A Dilution : 25 Reagent : 011924.R18; 020124.R15; 121223.R11; 020124.R16; 012924.R17; 020124.R18; 020124.R17; 041823.06 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914-G23536; 270638; GD220011; 3230800Y; 425204 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL) Supplemental pesticide screening using GC-MS/MS to quantitatively screen for Chlorfenapyr, Cyfluthrin, Cypermethrin, and Diazinon; as well as the qualitative confirmation of Dichlorvos, Permethrin, Piperonyl Butoxide, Prallethrin, Propiconazole, Pyrethrins, and Tebuconazole which are all quantitatively screened using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.154.AZ for analysis using a ThermoScientific 1310-series GC equipped with a TriPlus RSH autosampler and detected on a TSQ 9000-series mass spectrometer).</div>					
PROPOXUR	0.0050	ppm	0.2	PASS	ND						
TOTAL PYRETHRINS	0.0010	ppm	1	PASS	ND						
PYRIDABEN	0.0040	ppm	0.2	PASS	ND						

This Kaycha Labs Certification shall not be reproduced, unless in its entirety, without written approval from Kaycha Labs. The results relate only to the material or product analyzed. ND=Not Detected, ppm=Parts Per Million, ppb=Parts Per Billion, RSD=Relative Standard Deviation. Limit of Detection (LOD) and Limit Of Quantitation (LOQ) are terms used to describe the smallest concentration that can be detected and reliably measured by an analytical procedure, respectively. Action Levels are State-determined thresholds based on the action limits published in Table 3.1 of 9 A.A.C. 17 and 9 A.A.C. 18. The Measurement of Uncertainty (MU) error is available from the lab upon request. The "Decision Rule" for pass/fail does not include the MU. Any calculated totals may contain rounding errors.

Ariel Gonzales

Lab Director

State License #  
00000024LCMD66604568  
ISO 17025 Accreditation # 97164

Signature  
02/06/24



1231 W. Warner Road, Suite 105  
Tempe, AZ, 85284, US  
(480) 220-4470

Kaycha Labs

Social CBD Gel Caps Daily 2000mg 60ct

Matrix : Infused

Type: Capsule



# Certificate of Analysis

PASSED

e2e Pharma

3279 E. Harbour Drive  
Phoenix, AZ, 85034, US  
Telephone: (602) 737-0077  
Email: shannon.bard@e2epharmamfg.com

Sample : TE40131001-002

Harvest/Lot ID: 2400113

Batch# : 2400113

Sampled : 01/31/24

Ordered : 01/31/24

Sample Size Received : 62.44 gram

Total Amount : 1 units

Completed : 02/06/24 Expires: 02/06/25

Sample Method : SOP Client Method

Page 3 of 6



## Residual Solvents

PASSED

Solvents	LOD	Units	Action Level	Pass/Fail	Result
BUTANES	168.2000	ppm	5000	PASS	ND
METHANOL	87.7000	ppm	3000	PASS	ND
PENTANES	163.9000	ppm	5000	PASS	ND
ETHANOL	142.2000	ppm	5000	PASS	ND
ETHYL ETHER	193.1000	ppm	5000	PASS	ND
ACETONE	37.6000	ppm	1000	PASS	ND
2-PROPANOL	156.2000	ppm	5000	PASS	ND
ACETONITRILE	12.2000	ppm	410	PASS	ND
DICHLOROMETHANE	22.7000	ppm	600	PASS	ND
HEXANES	8.4000	ppm	290	PASS	ND
ETHYL ACETATE	179.0000	ppm	5000	PASS	ND
CHLOROFORM	2.4100	ppm	60	PASS	ND
BENZENE	0.1150	ppm	2	PASS	ND
ISOPROPYL ACETATE	168.6000	ppm	5000	PASS	ND
HEPTANE	152.8000	ppm	5000	PASS	ND
TOLUENE	26.2000	ppm	890	PASS	ND
XYLENES	53.2000	ppm	2170	PASS	ND

Analyzed by:  
334, 272, 333

Weight:  
0.02g

Extraction date:  
01/31/24 11:28:52

Extracted by:  
333

Analysis Method : SOP.T.40.044.AZ

Analytical Batch : TE003811SOL

Instrument Used : TE-092 "GC - Solvents 1", TE-095 "MS - Solvents 1", TE-098 "Injector - Solvents 1", TE-100 "HS - Solvents 1", TE-113 "Vacuum Pump - Solvents 1" Batch Date : 01/31/24 11:27:06

Analyzed Date : 01/31/24 16:25:36

Dilution : N/A

Reagent : 072722.01; 032023.04; 032023.03

Consumables : H109203-1; 428251; 19000-1; GD220011

Pipette : N/A

Residual solvents screening is performed using GC-MS which can detect below single digit ppm concentrations. (Method: SOP.T.40.044.AZ for sample prep and analysis via ThermoScientific 1310-series GC equipped with a TriPlus 500 Headspace autosampler and detection carried out by ISQ7000-series mass spectrometer). Butanes are reported as the sum of n-Butane and Isobutane. Pentanes are reported as the sum of n-Pentane, Isopentane, and Neopentane. Hexanes are reported as the sum of n-Hexane, 2-Methylpentane, 3-Methylpentane, 2,2-Dimethylbutane, and 2,3-Dimethylbutane. Xylenes are reported as the sum of Ethyl Benzene, m-Xylene, p-Xylene, and o-Xylene.

This Kaycha Labs Certification shall not be reproduced, unless in its entirety, without written approval from Kaycha Labs. The results relate only to the material or product analyzed. ND=Not Detected, ppm=Parts Per Million, ppb=Parts Per Billion, RSD=Relative Standard Deviation. Limit of Detection (LOD) and Limit Of Quantitation (LOQ) are terms used to describe the smallest concentration that can be detected and reliably measured by an analytical procedure, respectively. Action Levels are State-determined thresholds based on the action limits published in Table 3.1 of 9 A.A.C. 17 and 9 A.A.C. 18. The Measurement of Uncertainty (MU) error is available from the lab upon request. The "Decision Rule" for pass/fail does not include the MU. Any calculated totals may contain rounding errors.

Ariel Gonzales

Lab Director

State License #  
0000024LCMD66604568  
ISO 17025 Accreditation # 97164

Signature  
02/06/24



# Certificate of Analysis

**PASSED**

e2e Pharma

 3279 E. Harbour Drive  
 Phoenix, AZ, 85034, US  
 Telephone: (602) 737-0077  
 Email: shannon.bard@e2epharmamfg.com

Sample : TE40131001-002

Harvest/Lot ID: 2400113

Batch# : 2400113

Sampled : 01/31/24

Ordered : 01/31/24

Sample Size Received : 62.44 gram

Total Amount : 1 units

Completed : 02/06/24 Expires: 02/06/25

Sample Method : SOP Client Method

Page 4 of 6

	<b>Microbial</b>	<b>PASSED</b>
	<b>Mycotoxins</b>	<b>PASSED</b>

Analyte	LOD	Units	Result	Pass / Fail	Action Level
<b>SALMONELLA SPP</b>			Not Present in 1g	<b>PASS</b>	
<b>ESCHERICHIA COLI REC</b>	10.0000	CFU/g	<10	<b>PASS</b>	100
<b>TYM</b>	1.0000	Colonies	ND	<b>TESTED</b>	

Analyzed by: 96, 87, 272, 333 Weight: 1.5316g Extraction date: 02/01/24 09:14:37 Extracted by: 96

 Analysis Method : SOP.T.40.056B, SOP.T.40.058.FL, SOP.T.40.208, SOP.T.40.209.AZ  
 Analytical Batch : TE003812MIC Reviewed On : 02/02/24 13:55:58  
 Instrument Used : TE-234 "bioMerieux GENE-UP" Batch Date : 01/31/24 15:48:09  
 Analyzed Date : 02/02/24 09:52:19

 Dilution : 14  
 Reagent : 121423.01; 121423.10; 102523.47; 102523.54; 102523.60; 080423.50; 112223.32; 051923.14; 051923.29; 013024.R01; 020224.R01; 112223.18; 112223.19; 112223.20; 120123.01; 120123.04; 120123.07; 102523.64; 102523.65; 102523.68  
 Consumables : 22507; 33T797; L2063970; 210616-361-B; 1008443837; 20221115-071-B; 28521042; 062023CH01; 728914- G23536; 270638; NT10-1212; X002E5BZFT  
 Pipette : TE-053 SN:20E78952; TE-057 SN:21D58688; TE-058 SN:20C35427; TE-061 SN:20C35454; TE-062 SN:20C50491; TE-066 SN:20D56970; TE-069 SN:21B23920; TE-109 SN:20B18330; TE-256 Dispensette S Bottle Top Dispenser SN:20G36073; TE-258; TE-340 10-mL VWR Pipettor (SN: 17N4167)

Analyzed by: 87, 272, 333 Weight: 1.5349g Extraction date: 02/01/24 09:20:54 Extracted by: 96

 Analysis Method : N/A  
 Analytical Batch : TE003813TYM Reviewed On : 02/05/24 14:38:48  
 Instrument Used : N/A Batch Date : 01/31/24 16:04:04  
 Analyzed Date : N/A

 Dilution : N/A  
 Reagent : N/A  
 Consumables : N/A  
 Pipette : N/A

Total yeast and mold testing is performed utilizing MPN and traditional culture based techniques in accordance with F.S. Rule 64ER20-39.

Analyte	LOD	Units	Result	Pass / Fail	Action Level
<b>TOTAL AFLATOXINS</b>	1.4870	ppb	ND	<b>PASS</b>	20
<b>AFLATOXIN B1</b>	1.4700	ppb	ND	<b>PASS</b>	20
<b>AFLATOXIN B2</b>	1.8000	ppb	ND	<b>PASS</b>	20
<b>AFLATOXIN G1</b>	1.9000	ppb	ND	<b>PASS</b>	20
<b>AFLATOXIN G2</b>	3.2500	ppb	ND	<b>PASS</b>	20
<b>OCHRATOXIN A</b>	4.6100	ppb	ND	<b>PASS</b>	20

Analyzed by: 152, 39, 272, 333 Weight: 0.5028g Extraction date: 02/02/24 14:36:50 Extracted by: 152

 Analysis Method : SOP.T.30.500, SOP.T.30.104.AZ, SOP.T.40.104.AZ  
 Analytical Batch : TE003833MYC Reviewed On : 02/06/24 13:41:09  
 Instrument Used : N/A Batch Date : 02/02/24 10:31:19  
 Analyzed Date : 02/02/24 17:15:31

 Dilution : 25  
 Reagent : 012924.R17; 020124.R18; 020124.R17; 011924.R18; 020124.R15; 121223.R11; 020124.R16; 041823.06  
 Consumables : 947.100; 00334958-5; 1008443837; 28521042; 728914- G23536; 425204; 270638; GD220011; 323080IY  
 Pipette : TE-056 SN:21D58687; TE-060 SN:20C35457 (20-200uL); TE-108 SN:20B18337 (100-1000uL)

Aflatoxins B1, B2, G1, G2, and Ochratoxin A analysis using LC-MS/MS. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.104.AZ for sample prep, and SOP.T.40.104.AZ for analysis on ThermoScientific AltiS TSQ with Vanquish UHPLC). Total Aflatoxins (sum of Aflatoxins B1, B2, G1, G2) must be &lt;20µg/kg. Ochratoxin must be &lt;20µg/kg.



## Heavy Metals

**PASSED**

Metal	LOD	Units	Result	Pass / Fail	Action Level
<b>ARSENIC</b>	0.0030	ppm	ND	<b>PASS</b>	0.4
<b>CADMIUM</b>	0.0020	ppm	ND	<b>PASS</b>	0.4
<b>MERCURY</b>	0.0125	ppm	ND	<b>PASS</b>	1.2
<b>LEAD</b>	0.0010	ppm	ND	<b>PASS</b>	1

Analyzed by: 39, 272, 333 Weight: 0.1949g Extraction date: 02/01/24 09:45:05 Extracted by: 331,39

 Analysis Method : SOP.T.30.500, SOP.T.30.084.AZ, SOP.T.40.084.AZ  
 Analytical Batch : TE003821HEA

 Instrument Used : TE-051 "Metals Hood", TE-141 "Wolfgang", TE-307 "Ted", TE-308 "Ted Chiller", TE-310 "Ted AS", TE-309 "Ted Pump"  
 Analyzed Date : N/A

 Dilution : 50  
 Reagent : 101723.13; 012924.R05; 012924.R04; 091123.03; 011224.01; 090922.04  
 Consumables : 12622-306CE-306C; 28521042; 728914- G23536; 210725-598-D  
 Pipette : TE-110 SN:20B18338 (100-1000uL); TE-169 SN: 20B16352 (Nitric Acid)

Heavy Metals screening is performed using ICP-MS (Inductively Coupled Plasma - Mass Spectrometer) which can screen down to below single digit ppb concentrations for regulated heavy metals. (Methods: SOP.T.30.500 for sample homogenization, SOP.T.30.084.AZ for sample prep by microwave digestion, and SOP.T.40.084.AZ for analysis by ThermoScientific iCAP RQ ICP-MS).



1231 W. Warner Road, Suite 105  
Tempe, AZ, 85284, US  
(480) 220-4470

Kaycha Labs

Social CBD Gel Caps Daily 2000mg 60ct  
Matrix : Infused  
Type: Capsule



# Certificate of Analysis

**PASSED**

e2e Pharma

3279 E. Harbour Drive  
Phoenix, AZ, 85034, US  
Telephone: (602) 737-0077  
Email: shannon.bard@e2epharmamfg.com

Sample : TE40131001-002  
Harvest/Lot ID: 2400113

Batch# : 2400113  
Sampled : 01/31/24  
Ordered : 01/31/24

Sample Size Received : 62.44 gram  
Total Amount : 1 units  
Completed : 02/06/24 Expires: 02/06/25  
Sample Method : SOP Client Method

Page 5 of 6



**Filth/Foreign Material**

**PASSED**

Analyte	LOD	Units	Result	P/F	Action Level
Filth and Foreign Material	0.3000	%	ND	PASS	3
Analyzed by: 87, 272, 333	Weight: 1.5316g	Extraction date: 02/06/24 16:15:04		Extracted by: 87	
Analysis Method : SOP.T.40.090					
Analytical Batch : TE003814FIL		Reviewed On : 02/06/24 16:40:18			
Instrument Used : N/A		Batch Date : 01/31/24 16:05:11			
Analyzed Date : N/A					
Dilution : N/A					
Reagent : N/A					
Consumables : N/A					
Pipette : N/A					

Includes, but is not limited to: hair, insects, feces, packaging contaminants, and manufacturing waste/by-products.  
(Method: SOP.T.40.090 using an SH-2B/T Stereo Microscope). Testing result is for informational purposes only and cannot be used to satisfy dispensary testing requirements in R9-17-317.01(A) or labeling requirements in R9-17-317. Nor, can it be used to satisfy marijuana establishment testing requirements in R9-18-311(A) or labeling requirements in R9-18-310 - Q3.

This Kaycha Labs Certification shall not be reproduced, unless in its entirety, without written approval from Kaycha Labs. The results relate only to the material or product analyzed. ND=Not Detected, ppm=Parts Per Million, ppb=Parts Per Billion, RSD=Relative Standard Deviation. Limit of Detection (LOD) and Limit Of Quantitation (LOQ) are terms used to describe the smallest concentration that can be detected and reliably measured by an analytical procedure, respectively. Action Levels are State-determined thresholds based on the action limits published in Table 3.1 of 9 A.A.C. 17 and 9 A.A.C. 18. The Measurement of Uncertainty (MU) error is available from the lab upon request. The "Decision Rule" for pass/fail does not include the MU. Any calculated totals may contain rounding errors.

**Ariel Gonzales**

Lab Director

State License #  
0000024LCMD66604568  
ISO 17025 Accreditation # 97164

Signature  
02/06/24



1231 W. Warner Road, Suite 105  
Tempe, AZ, 85284, US  
(480) 220-4470

Kaycha Labs

Social CBD Gel Caps Daily 2000mg 60ct  
Matrix : Infused  
Type: Capsule



# Certificate of Analysis

PASSED

e2e Pharma

3279 E. Harbour Drive  
Phoenix, AZ, 85034, US  
Telephone: (602) 737-0077  
Email: shannon.bard@e2epharmamfg.com

Sample : TE40131001-002  
Harvest/Lot ID: 2400113

Batch# : 2400113  
Sampled : 01/31/24  
Ordered : 01/31/24

Sample Size Received : 62.44 gram  
Total Amount : 1 units  
Completed : 02/06/24 Expires: 02/06/25  
Sample Method : SOP Client Method

Page 6 of 6

## COMMENTS

- \* Pesticide TE40131001-002PES
  - 1 - M1: Bifenazate, Fipronil, Prallethrin.
- \* Residual TE40131001-002SOL
  - 1 - M2: o-Xylene
- \* Total Yeast and Mold TE40131001-002TYM
  - 1 - Q3 Informational

This Kaycha Labs Certification shall not be reproduced, unless in its entirety, without written approval from Kaycha Labs. The results relate only to the material or product analyzed. ND=Not Detected, ppm=Parts Per Million, ppb=Parts Per Billion, RSD=Relative Standard Deviation. Limit of Detection (LOD) and Limit Of Quantitation (LOQ) are terms used to describe the smallest concentration that can be detected and reliably measured by an analytical procedure, respectively. Action Levels are State-determined thresholds based on the action limits published in Table 3.1 of 9 A.A.C. 17 and 9 A.A.C. 18. The Measurement of Uncertainty (MU) error is available from the lab upon request. The "Decision Rule" for pass/fail does not include the MU. Any calculated totals may contain rounding errors.

Ariel Gonzales

Lab Director

State License #  
00000024LCMD66604568  
ISO 17025 Accreditation # 97164

Signature  
02/06/24