



Customer: Sentia Wellness
Product identity: Volcom Muscle Balm Stick VMBS25374 A
Client/Metric ID: .
Laboratory ID: 20-001672-0001 **Sample Date:** 02/11/20 13:00

Summary

Potency:

| Analyte | Result | Limits | Units | Status | |
|-----------------|--------|--------|--------|--------|--|
| CBD | 0.184 | | % | | CBD-Total per 75g 138 mg/75g |
| Analyte per 75g | Result | Limits | Units | Status | |
| CBD per 75g | 138 | | mg/75g | | THC-Total per 75g <LOQ (Reported in milligrams per serving) |

Residual Solvents:

| Analyte | Result (µg/g) | Limits (µg/g) | Status |
|----------------------|------------------|------------------|--------|
| Ethanol ¹ | 1460 | | |

Pesticides:

All analytes passing and less than LOQ.

Metals:

Less than LOQ for all analytes.

Microbiology:

Less than LOQ for all analytes.



Customer: Sentia Wellness
PO Box 15309
Portland Oregon 97293
United States

Product identity: Volcom Muscle Balm Stick VMBS25374 A

Client/Metric ID: .

Sample Date: 02/11/20 13:00

Laboratory ID: 20-001672-0001

Relinquished by: UPS

Temp: 14.6 °C

Serving Size #1: 75 g

Sample Results

| Potency | | Batch: 2001433 | | | | | | |
|-------------|--------|----------------|-------|--------|----------|-------------------|-------|--|
| Analyte | Result | Limits | Units | LOQ | Analyze | Method | Notes | |
| CBC† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBC-A† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBC-Total† | < LOQ | | % | 0.0059 | 02/17/20 | J AOAC 2015 V98-6 | | |
| CBD | 0.184 | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBD-A | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBD-Total | 0.184 | | % | 0.0059 | 02/17/20 | J AOAC 2015 V98-6 | | |
| CBDV† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBDV-A† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBDV-Total† | < LOQ | | % | 0.0059 | 02/17/20 | J AOAC 2015 V98-6 | | |
| CBG† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBG-A† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBG-Total† | < LOQ | | % | 0.0059 | 02/17/20 | J AOAC 2015 V98-6 | | |
| CBL† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| CBN | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| Δ8-THC† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| Δ9-THC | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| THC-A | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| THC-Total | < LOQ | | % | 0.0059 | 02/17/20 | J AOAC 2015 V98-6 | | |
| THCV† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| THCV-A† | < LOQ | | % | 0.0032 | 02/13/20 | J AOAC 2015 V98-6 | | |
| THCV-Total† | < LOQ | | % | 0.0059 | 02/17/20 | J AOAC 2015 V98-6 | | |

| Microbiology | | | | | | | | |
|-------------------------|--------|--------|-------|-----|---------|----------|-------------------------|-------|
| Analyte | Result | Limits | Units | LOQ | Batch | Analyze | Method | Notes |
| E.coli | < LOQ | | cfu/g | 10 | 2001366 | 02/15/20 | AOAC 991.14 (Petrifilm) | X |
| Total Coliforms | < LOQ | | cfu/g | 10 | 2001366 | 02/15/20 | AOAC 991.14 (Petrifilm) | X |
| Mold (RAPID Petrifilm) | < LOQ | | cfu/g | 10 | 2001364 | 02/14/20 | AOAC 2014.05 (RAPID) | X |
| Yeast (RAPID Petrifilm) | < LOQ | | cfu/g | 10 | 2001364 | 02/14/20 | AOAC 2014.05 (RAPID) | X |

Test results relate only to the parameters tested and to the samples as received by the laboratory. Test results meet all requirements of NELAP and the Pixis quality assurance plan unless otherwise noted. This report shall not be reproduced, except in full, without the written consent of this laboratory. Samples will be retained for a maximum of 30 days from the receipt date unless prior arrangements have been made.



| Solvents | | | | | Method EPA5021A | Units µg/g | Batch 2001426 | Analyze 02/14/20 10:01 AM | | | |
|-------------------------|--------|--------|------|--------|-----------------|----------------------|---------------|---------------------------|------|--------|-------|
| Analyte | Result | Limits | LOQ | Status | Notes | Analyte | Result | Limits | LOQ | Status | Notes |
| 1,4-Dioxane | < LOQ | 380 | 100 | pass | | 2-Butanol | < LOQ | 5000 | 200 | pass | |
| 2-Ethoxyethanol | < LOQ | 160 | 30.0 | pass | | 2-Methylbutane | < LOQ | | 200 | | |
| 2-Methylpentane | < LOQ | | 30.0 | | | 2-Propanol (IPA) | < LOQ | 5000 | 200 | pass | |
| 2,2-Dimethylbutane | < LOQ | | 30.0 | | | 2,2-Dimethylpropane | < LOQ | | 200 | | |
| 2,3-Dimethylbutane | < LOQ | | 30.0 | | | 3-Methylpentane | < LOQ | | 30.0 | | |
| Acetone | < LOQ | 5000 | 200 | pass | | Acetonitrile | < LOQ | 410 | 100 | pass | |
| Benzene | < LOQ | 2.00 | 1.00 | pass | | Butanes (sum) | < LOQ | 5000 | 400 | pass | |
| Cyclohexane | < LOQ | 3880 | 200 | pass | | Ethanol ¹ | 1460 | | 200 | | |
| Ethyl acetate | < LOQ | 5000 | 200 | pass | | Ethyl benzene | < LOQ | | 200 | | |
| Ethyl ether | < LOQ | 5000 | 200 | pass | | Ethylene glycol | < LOQ | 620 | 200 | pass | |
| Ethylene oxide | < LOQ | 50.0 | 30.0 | pass | | Hexanes (sum) | < LOQ | 290 | 150 | pass | |
| Isopropyl acetate | < LOQ | 5000 | 200 | pass | | Isopropylbenzene | < LOQ | 70.0 | 30.0 | pass | |
| m,p-Xylene | < LOQ | | 200 | | | Methanol | < LOQ | 3000 | 200 | pass | |
| Methylene chloride | < LOQ | 600 | 200 | pass | | Methylpropane | < LOQ | | 200 | | |
| n-Butane | < LOQ | | 200 | | | n-Heptane | < LOQ | 5000 | 200 | pass | |
| n-Hexane | < LOQ | | 30.0 | | | n-Pentane | < LOQ | | 200 | | |
| o-Xylene | < LOQ | | 200 | | | Pentanes (sum) | < LOQ | 5000 | 600 | pass | |
| Propane | < LOQ | 5000 | 200 | pass | | Tetrahydrofuran | < LOQ | 720 | 100 | pass | |
| Toluene | < LOQ | 890 | 100 | pass | | Total Xylenes | < LOQ | | 400 | | |
| Total Xylenes and Ethyl | < LOQ | 2170 | 600 | pass | | | | | | | |



Pesticides Method AOAC 2007.01 & EN 15662 (mod) Units mg/kg Batch 2001431 Analyze 02/14/20 10:24 AM

| Analyte | Result | Limits | LOQ | Status | Notes | Analyte | Result | Limits | LOQ | Status | Notes |
|------------------|--------|--------|-------|--------|-------|---------------------|--------|--------|-------|--------|-------|
| Abamectin | < LOQ | 0.50 | 0.250 | pass | | Acephate | < LOQ | 0.40 | 0.250 | pass | |
| Acequinocyl | < LOQ | 2.0 | 1.00 | pass | | Acetamiprid | < LOQ | 0.20 | 0.100 | pass | |
| Aldicarb | < LOQ | 0.40 | 0.200 | pass | | Azoxystrobin | < LOQ | 0.20 | 0.100 | pass | |
| Bifenazate | < LOQ | 0.20 | 0.100 | pass | | Bifenthrin | < LOQ | 0.20 | 0.100 | pass | |
| Boscalid | < LOQ | 0.40 | 0.200 | pass | | Carbaryl | < LOQ | 0.20 | 0.100 | pass | |
| Carbofuran | < LOQ | 0.20 | 0.100 | pass | | Chlorantraniliprole | < LOQ | 0.20 | 0.100 | pass | |
| Chlorfenapyr | < LOQ | 1.0 | 0.500 | pass | | Chlorpyrifos | < LOQ | 0.20 | 0.100 | pass | |
| Clofentezine | < LOQ | 0.20 | 0.100 | pass | | Cyfluthrin | < LOQ | 1.0 | 0.500 | pass | |
| Cypermethrin | < LOQ | 1.0 | 0.500 | pass | | Daminozide | < LOQ | 1.0 | 0.500 | pass | |
| Diazinon | < LOQ | 0.20 | 0.100 | pass | | Dichlorvos | < LOQ | 1.0 | 0.500 | pass | |
| Dimethoate | < LOQ | 0.20 | 0.100 | pass | | Ethoprophos | < LOQ | 0.20 | 0.100 | pass | |
| Etofenprox | < LOQ | 0.40 | 0.200 | pass | | Etoxazole | < LOQ | 0.20 | 0.100 | pass | |
| Fenoxycarb | < LOQ | 0.20 | 0.100 | pass | | Fenpyroximate | < LOQ | 0.40 | 0.200 | pass | |
| Fipronil | < LOQ | 0.40 | 0.200 | pass | | Fonicamid | < LOQ | 1.0 | 0.400 | pass | |
| Fludioxonil | < LOQ | 0.40 | 0.200 | pass | | Hexythiazox | < LOQ | 1.0 | 0.400 | pass | |
| Imazalil | < LOQ | 0.20 | 0.100 | pass | | Imidacloprid | < LOQ | 0.40 | 0.200 | pass | |
| Kresoxim-methyl | < LOQ | 0.40 | 0.200 | pass | | Malathion | < LOQ | 0.20 | 0.100 | pass | |
| Metalaxyl | < LOQ | 0.20 | 0.100 | pass | | Methiocarb | < LOQ | 0.20 | 0.100 | pass | |
| Methomyl | < LOQ | 0.40 | 0.200 | pass | | MGK-264 | < LOQ | 0.20 | 0.100 | pass | |
| Myclobutanil | < LOQ | 0.20 | 0.100 | pass | | Naled | < LOQ | 0.50 | 0.250 | pass | |
| Oxamyl | < LOQ | 1.0 | 0.500 | pass | | Paclobutrazole | < LOQ | 0.40 | 0.200 | pass | |
| Parathion-Methyl | < LOQ | 0.20 | 0.200 | pass | | Permethrin | < LOQ | 0.20 | 0.100 | pass | |
| Phosmet | < LOQ | 0.20 | 0.100 | pass | | Piperonyl butoxide | < LOQ | 2.0 | 1.00 | pass | |
| Prallethrin | < LOQ | 0.20 | 0.200 | pass | | Propiconazole | < LOQ | 0.40 | 0.200 | pass | |
| Propoxur | < LOQ | 0.20 | 0.100 | pass | | Pyrethrin I (total) | < LOQ | 1.0 | 0.500 | pass | |
| Pyridaben | < LOQ | 0.20 | 0.100 | pass | | Spinosad | < LOQ | 0.20 | 0.100 | pass | |
| Spiromesifen | < LOQ | 0.20 | 0.100 | pass | | Spirotetramat | < LOQ | 0.20 | 0.100 | pass | |
| Spiroxamine | < LOQ | 0.40 | 0.200 | pass | | Tebuconazole | < LOQ | 0.40 | 0.200 | pass | |
| Thiacloprid | < LOQ | 0.20 | 0.100 | pass | | Thiamethoxam | < LOQ | 0.20 | 0.100 | pass | |
| Trifloxystrobin | < LOQ | 0.20 | 0.100 | pass | | | | | | | |

Metals

| Analyte | Result | Limits | Units | LOQ | Batch | Analyze | Method | Notes |
|---------|--------|--------|-------|--------|---------|----------|---------------------|-------|
| Arsenic | < LOQ | | mg/kg | 0.0483 | 2001410 | 02/13/20 | AOAC 2013.06 (mod.) | X |
| Cadmium | < LOQ | | mg/kg | 0.0483 | 2001410 | 02/13/20 | AOAC 2013.06 (mod.) | X |
| Lead | < LOQ | | mg/kg | 0.0483 | 2001410 | 02/13/20 | AOAC 2013.06 (mod.) | X |
| Mercury | < LOQ | | mg/kg | 0.0241 | 2001410 | 02/13/20 | AOAC 2013.06 (mod.) | X |

Test results relate only to the parameters tested and to the samples as received by the laboratory. Test results meet all requirements of NELAP and the Pixis quality assurance plan unless otherwise noted. This report shall not be reproduced, except in full, without the written consent of this laboratory. Samples will be retained for a maximum of 30 days from the receipt date unless prior arrangements have been made.



Mycotoxins

| Analyte | Result | Limits | Units | LOQ | Batch | Analyze | Method | Notes |
|-----------------------------|--------|--------|-------|------|---------|----------|-------------------------|-------|
| Aflatoxin B1 [†] | < LOQ | | µg/kg | 5.00 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Aflatoxin B2 [†] | < LOQ | | µg/kg | 5.00 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Aflatoxin G1 [†] | < LOQ | | µg/kg | 5.00 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Aflatoxin G2 [†] | < LOQ | | µg/kg | 5.00 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Deoxynivalenol [†] | < LOQ | | µg/kg | 200 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Fumonisin B1 [†] | < LOQ | | µg/kg | 200 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Fumonisin B2 [†] | < LOQ | | µg/kg | 200 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| HT2-Toxin [†] | < LOQ | | µg/kg | 40.0 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Nivalenol [†] | < LOQ | | µg/kg | 400 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Ochratoxin A [†] | < LOQ | | µg/kg | 5.00 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Ochratoxin B [†] | < LOQ | | µg/kg | 2.00 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| T2-Toxin [†] | < LOQ | | µg/kg | 20.0 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |
| Zearalenone [†] | < LOQ | | µg/kg | 200 | 2001457 | 02/14/20 | AOAC 2007.01 & EN 15662 | |



These test results are representative of the individual sample selected and submitted by the client.

Abbreviations

Limits: Action Levels per OAR-333-007-0400, OAR-333-007-0210, OAR-333-007-0220

Limit(s) of Quantitation (LOQ): The minimum levels, concentrations, or quantities of a target variable (e.g., target analyte) that can be reported with a specified degree of confidence.

† = Analyte not NELAP accredited.

Units of Measure

cfu/g = Colony forming units per gram

g = Gram

µg/g = Microgram per gram

µg/kg = Micrograms per kilogram = parts per billion (ppb)

mg/kg = Milligram per kilogram = parts per million (ppm)

mg/75g = Milligram per 75g

% = Percentage of sample

% wt = µg/g divided by 10,000

Glossary of Qualifiers

X: Not ORELAP accredited.

Approved Signatory

Derrick Tanner
General Manager